



DRIVER
DRIVER APP

Driver Guide

Scan the sticker. Drive.

Version 1.0 · August 2026

Get set up (one time)



1 • ACTIVATE WITH YOUR CODE

Your manager gives you a 6-digit activation code — on a card or by text.

Open driver.envisiontelematics.com/app on your phone, enter the code, tap Activate.

Codes are one-time and expire 14 days after they're issued. Need a new one? Ask your manager.

2 • ADD DRIVER TO YOUR HOME SCREEN (RECOMMENDED)

- **iPhone:**
In Safari, tap the Share button, then “Add to Home Screen.”
- **Android:**
In Chrome, tap the menu (■), then “Add to Home screen.”

Driver opens like an app — no downloads, no app store, nothing to update.

ONE PHONE AT A TIME

Your Driver session works in one place at a time. If you activate on a new phone or browser, the old one signs out automatically. If you ever see “Session not recognized,” just enter a fresh code from your manager.

GOOD TO KNOW

- **No tracking app.**
Driver is not a GPS tracker on your phone. Location is captured only when you submit a vehicle inspection — for the inspection record itself.
- **Your data.**
Sign-ins and inspections are recorded to your fleet's Geotab system — the same system your trucks already report to.

Start your day: sign in to your truck



Every Driiver vehicle has a QR sticker on the dash. Any of these three ways signs you in:

1 Scan inside the app

Open Driiver → Scan tab → point at the sticker.
It locks on in a second or two.

2 Scan with your phone camera

Point your camera app at the sticker and tap the link.
Driiver opens in your browser, already signed in.

3 Type the vehicle code

Camera trouble? Tap “Enter vehicle code” and type the
6-character code printed under the QR on the sticker.

AFTER YOU'RE SIGNED IN

- **You're covered all day.**
Trips and safety events record to you. Short stops don't need a re-scan.
- **Auto-release at 11:59 PM.**
Your assignment ends automatically each night.
- **Switching trucks?**
Tap “Log out of vehicle,” then scan the new truck's sticker.

MY DAY (IF YOUR FLEET HAS DRIIVER PRO)

The My Day tab shows your trips, miles, and any safety exceptions — your own scorecard, straight from the same data your fleet sees.

Vehicle inspections (Driver Pro)



On My Vehicle, tap Pre-trip before you roll — or Post-trip when you're done.

THE WALK-AROUND, ONE ITEM AT A TIME

- **One card per item.**
Look at the truck, tap ✓ Pass — the next item slides in. Ten items, about 90 seconds.
- **Something wrong? Tap X Flag.**
Describe the issue and add a photo (some items require one).
Then Continue.
- **Review at the end.**
Every item listed — tap any row to change it.

SUBMITTING

Certify & submit — safe to operate

Everything passed. You're certified and done.

Submit with defects

Your flags, notes, and photos go straight to your manager in Geotab for repair.

Time and location are captured automatically — you never type them. Your inspection is a signed record in your fleet's Geotab system, same as a paper DVIR, minus the paper.

VEHICLE HEALTH

The Vehicle Health tile shows your truck's active faults and check-engine status. Tap it for the full list. See something critical? Tell your manager before you roll.

NEED HELP?

Your fleet administrator can reissue codes and fix access. App questions: support@envisiontelematics.com